

SnappyTag

USER GUIDE

Thank you for purchasing **Snappy Tags**, the new one-click way to label clothes. Your kit comprises tags, backs and Snappy applicator with incorporated removal tool.

Your tags have been laser-etched with the details specified on your order (e.g. names and/or numbers). The **Snappy Tags** incorporate a tiny stem which the applicator taps through the fabric of the garment and into the back to provide a secure and safe fixing method.

Where to apply the tag...

We recommend that the tag is applied to the clothing label which is usually located on the left-hand side of the item of clothing, or alternatively, on the seam of the garment. Do not apply **Snappy Tags** to the collar of the garment, as it may cause irritation to the wearer.

Snappy Tags should not be applied to underwear or socks that press directly against the skin. Place them in a mesh laundry bag (available separately) then **Snappy Tag** the bag! Saves you buying lots of tags and keeps paired socks together!

See Over For How To Apply...

Brought to you by



HOW TO APPLY...

SnappyTag

How It Works:



Place the strip containing the Snappy Backs in the bottom of the applicator and push until it clicks. Pop the etched Tag into the top of the applicator:



Insert the garment into the mouth of the applicator and press together until you hear it click. Open the applicator and the Tag is applied to the garment.



To apply the next Tag — pull the Snappy Back strip until it has clicked into place.



**WANT TO USE THE TAG AGAIN?
EASY!**

Just remove the Tag using the applicator removal section and re-apply to a new garment using a new Snappy Back. Discard the used Snappy Back.

Visit www.snappytags.co.uk or call (01482) 638355